Cod. 1.045511 - Rev. ST.005313/001

IE

VERTICAL CONNECTION KIT 1 OR 2 ZONE SUPER TRIO TOP
CODE 3.031193

GENERAL WARNINGS.

All products are protected with suitable transport packaging. The material must be stored in dry environments and protected against weathering. This instruction manual provides technical information for installing the kit. As for the other issues related to kit installation (e.g. safety in the work site, environment protection, injury prevention), it is necessary to comply with the provisions specified in the regulations in force and principles of good practice.

Improper installation or assembly of the appliance and/or compo-nents, accessories, kit and devices can cause unexpected problems to people, animals and objects. Read the instructions provided with the product carefully to ensure a proper installation. Installation and maintenance must be performed in compliance with the regulations in force, according to the manufacturer's instructions and by authorised professionally qualified staff, intending staff with specific technical skills in the plant sector, as envisioned by the Law.

Cod. 1.045511 - Rev. ST.005313/001

IE

VERTICAL CONNECTION KIT 1 OR 2 ZONE SUPER TRIO TOP
CODE 3.031193

GENERAL WARNINGS.

All products are protected with suitable transport packaging. The material must be stored in dry environments and protected against weathering.
This instruction manual provides technical information for installing the kit. As for the other issues related to kit installation (e.g. safety in the work site, environment protection, injury prevention), it is necessary to comply with the provisions specified in the regulations in force and principles of good practice.
Improper installation or assembly of the appliance and/or compo-nents, accessories, kit and devices can cause unexpected problems to people, animals and objects.
Read the instructions provided with the product carefully to ensure a proper installation. Installation and maintenance must be performed in compliance with the regulations in force, according to the manufacturer's instructions and by authorised professionally qualified staff, intending staff with specific technical skills in the plant sector, as envisioned by the Law.

KIT INSTALLATION.

Assemble the connection unit as shown in the figure, taking care to interpose the gaskets.
To prevent water from being able to infiltrate into the masonry, seal all the passages between the connection pipes and recessed frame.
N.B.: when installation is completed, check the hydraulic circuit by performing a leak test.

Kit composition

Ref.	Description	Qty
1	Vertical central heating connection pipe	4
2	Vertical domestic hot water connection pipe	2
3	Insulation	4
4	Gasket 30x22x2	4
5	G 1" fitting	4

Ref.	Description	Qty
6	G 1/2" fitting	1
7	Gasket 18.5x11.5x2	2
8	G 1/2" ball valve	1
9	G 1" nut	4
10	G 1/2" nut	2

Key: *AC - 1/2" domestic hot water outlet*
AF - 1/2" domestic hot water inlet
RZ1 - Zone 1 1" system return
MZ1 - Zone 1 1" system flow
RZ2 - Zone 2 1" system return
MZ2 - Zone 2 1" system flow

